| Legend for fold-out page | | |
|--------------------------|--|----------------------|
| Pos. | Description | Detailed information |
| | Function module E82ZAFSC / E82ZAFSC001 | |
| Α | Switch for the configuration of the analog input (terminal X3/8) | |
| В | Digital and analog inputs and outputs, terminal strip X3 | □ 39 |
| С | Nameplate | □ 32 |

24

| 1 | About this documentation | 26 |
|---|---|-----------------------|
| | Conventions used | 27 28 |
| 2 | Safety instructions | 29 |
| 3 | Product description | 30 |
| | Function Application as directed Scope of supply Identification | 30 30 31 32 |
| 4 | Technical data | 33 |
| | Connection data Operating conditions Dimensions | 33 33 34 |
| 5 | Mechanical installation | 35 |
| 6 | Electrical installation Wiring according to EMC Wiring | 36 36 37 |
| 7 | Commissioning | 40 |
| | Before switching on DIP switch position Complications done | 40 41 |

About this documentation 1

Contents

This documentation includes

- ▶ Information about the mechanical and electrical installation of the function module:
- ► Information about the commissioning of the function module;
- Safety instructions which you must observe in any case;
- ▶ Data about the versions of Lenze basic devices to be used:
- ► Technical data

Validity information

The information given in this documentation is valid for the following devices:

| Function module | Type designation | As of hardware version |
|-----------------------|------------------|------------------------|
| STANDARD I/O | E82ZAFSC | 3A |
| STANDARD I/O (coated) | E82ZAFSC001 | 3A |

Target group

This documentation is directed at persons who install and commission the described product according to the project requirements.



Documentation and software updates for further Lenze products can be found on the Internet in the "Services & Downloads" area under

http://www.Lenze.com

1

Conventions used

Conventions used

This documentation uses the following conventions to distinguish between different types of information:

| Type of information | Identification | Examples/notes | |
|---------------------|----------------|--|--|
| Numbers | | | |
| Decimal separator | Point | The decimal point is used throughout this documentation. Example: 1234.56 | |
| Symbols | | | |
| Page reference | Ш | Reference to another page with additional information Example: 16 = see page 16 | |

1 About this documentation

Notes used

Notes used

The following pictographs and signal words are used in this documentation to indicate dangers and important information:

Safety instructions

Structure of safety instructions:



Danger!

(characterises the type and severity of danger)

Note

(describes the danger and gives information about how to prevent dangerous situations)

| Pictograph and signal word | Meaning | |
|----------------------------|--|--|
| Danger! | Danger of personal injury through dangerous electrical voltage. Reference to an imminent danger that may result in death or serious personal injury if the corresponding measures are not taken. | |
| ⚠ Danger! | Danger of personal injury through a general source of danger. Reference to an imminent danger that may result in death or serious personal injury if the corresponding measures are not taken. | |
| Stop! | Danger of property damage. Reference to a possible danger that may result in property damage if the corresponding measures are not taken. | |

Application notes

| Pictograph and signal word | Meaning |
|----------------------------|--|
| Note! | Important note to ensure troublefree operation |
| - ૄ૽ - Tip! | Useful tip for simple handling |
| (| Reference to another documentation |





Danger!

Inappropriate handling of the function module and the basic device can cause serious injuries to persons and damage to material assets.

Observe the safety instructions and residual hazards included in the documentation of the basic device.



Stop!

Electrostatic discharge

Electronic components within the function module can be damaged or destroyed by electrostatic discharge.

Possible consequences:

▶ The function module is defective.

Protective measures

▶ Free yourself from any electrostatic charge before you touch the module.

3 Product description

Function

Function

The function module allows the control of Lenze frequency inverters and the Lenze Drive PLC with analog and digital control signals.

Application as directed

The function module ...

▶ is an accessories unit which can be used with the following Lenze basic devices:


| Function module | Lenze basic devices | | |
|-----------------|---------------------|--------------|------------------------|
| | Product range | Product name | As of hardware version |
| E82ZAFSC | Frequency inverter | 8200 vector | Vx14 |
| | Drive PLC | Drive PLC | 1x20 |
| E82ZAFSC001 | Frequency inverter | 8200 motec | Vx14 |

- ▶ is an equipment to be used in industrial power systems.
- allows for the control of Lenze frequency inverters and the Lenze Drive PLC with analog and digital control signals.

Any other use shall be deemed inappropriate!

Scope of supply

Scope of supply





| Pos. | Scope of supply | |
|------|--|--|
| | Function module E82ZAFSC / E82ZAFSC001 | |
| D | Screw driver | |
| E | Sticker | |
| | Mounting Instructions | |

3 Product description

Identification

Identification





Connection data

Connection data

| X3/ | Values | | |
|------------------------|---|--|--|
| 62 | Resolution: 10 bit Linearity distortion: ±0.5 % Temperature distortion: 0.3 % (0 +60 °C) Carrying capacity I _{max} = 2 mA | | |
| 8 | Resolution: 10 bit Linearity distortion: $\pm 0.5\%$ Temperature distortion: 0.3% (0 $+60$ °C) Input resistance Rinput > 50 k Ω (with voltage signal) Rinput = 250 Ω (with current signal) | | |
| 9 | Carrying capacity I _{max} = 10 mA | | |
| 7 | isolated from terminal X3/39 (GND2) | | |
| 20 | Load capacity: Σ I _{max} = 40 mA | | |
| 28 E1 ¹⁾ | Input resistance: 3.3 kΩ | | |
| E2 1) | 1 = HIGH (+12 +30 V), PLC level, HTL | | |
| E3 | 0 = LOW (0 +3 V), PLC level, HTL | | |
| E4 | | | |
| 39 | isolated from terminal X3/7 (GND1) | | |
| A1 | Load capacity: I _{max} = 10 mA, with internal supply I _{max} = 50 mA, with external supply | | |

¹⁾ Frequency input alternatively 0 ... 10 kHz single-track or 0 ... 1 kHz two-track, config. via C0425


Operating conditions

| Ambient conditions | | | | |
|--------------------|-----------|---|-----------------------|--|
| Climate | | | | |
| | Storage | IEC/EN 60721-3-1 | 1K3 (-25 to +60 °C) | |
| | Transport | IEC/EN 60721-3-2 | 2K3 (-25 to +70 °C) | |
| | Operation | Corresponding to the data of the Lenze basic device used (see documentation of the basic device). | | |
| | Pollution | EN 61800-5-1 | Degree of pollution 2 | |

4 Technical data

Dimensions

Dimensions



All dimensions in mm