

AquaProbe FEA100 / FEA200

Electromagnetic flowmeter

Insertion-type flow sensors

Maximum performance,
minimum hassle



Introduction

The AquaProbe FEA100 / FEA200 flow sensor is designed for measurement of the velocity of water. The flow sensor is available in four standard lengths and can be installed in any pipeline of internal diameter from 200 mm (8 in.) to 8000 mm (360 in.), through a small tapping.

The flow sensor is designed for use in survey applications such as leakage monitoring and network analysis and in permanent locations where cost or space limitations preclude the use of conventional closed pipe meters.

This User Guide provides installation, connection, security, start-up and basic setup details for the flow sensor only. The AquaProbe sensor is available for operation with either a WaterMaster transmitter (FET100) or an AquaMaster3 transmitter (FET200).

This User Guide should be used in conjunction with the following publications:

WaterMaster flowmeter (FEA100):

- User Guide – OI/FET100-EN
- Programming Guide – IM/WMP
- User Guide Supplement, PROFIBUS RS485 Physical Layer (FEX100-DP) – IM/WMPBS-EN
- User Guide Supplement, PROFIBUS FEX100-DP Parameter Tables – IM/WMPBST-EN

AquaMaster flowmeter (FEA200):

- User Guide – OI/FET200-EN
- Programming Guide COI/FET2XX-EN
- MODBUS Tables Supplement – COI/FET2XX/MOD/TBL-EN

ScrewDriver profiling and Configuration software:

- User Guide – OI/SDR

The Company

We are an established world force in the design and manufacture of instrumentation for industrial process control, flow measurement, gas and liquid analysis and environmental applications.

As a part of ABB, a world leader in process automation technology, we offer customers application expertise, service and support worldwide.

We are committed to teamwork, high quality manufacturing, advanced technology and unrivalled service and support.

The quality, accuracy and performance of the Company's products result from over 100 years experience, combined with a continuous program of innovative design and development to incorporate the latest technology.

Quality Control

The UKAS Calibration Laboratory No. 0255 is just one of the ten flow calibration plants operated by the Company and is indicative of our dedication to quality and accuracy.



UKAS Calibration Laboratory No. 0255

AquaProbe FEA100 / FEA200

Electromagnetic flowmeter – insertion-type flow sensors

1	Safety	3
1.1	Health & Safety	3
1.2	Electrical Safety – CEI/IEC 61010-1:2001-2	3
1.3	Symbols – CEI/IEC 61010-1:2001-2	3
1.4	Product Recycling Information	4
1.5	Product Disposal	5
1.6	Restriction of Hazardous Substances (RoHS)	5
1.7	Chemical Reagents	5
1.8	Safety Precautions	5
1.9	Safety Conventions	6
1.10	Safety Recommendations	6
1.11	Service and Repairs	6
1.12	Potential Safety Hazards	6
2	System Schematic	7
3	Mechanical Installation	8
3.1	Location – Environmental Conditions	8
3.2	Use	9
3.3	Location – Flow Conditions	10
3.3.1	International Standard for Flow Measurement	11
3.3.2	Velocity Limitations	11
3.4	Location – Mechanical	13
3.5	Safety	14
3.6	Installing the Flow Sensor	15
3.7	Setting the Insertion Depth	16
3.7.1	Centre Line Method for Pipe Diameters ≤ 1 m (≤ 40 in.)	16
3.7.2	Centre Line Method for Pipe Diameters > 1 m ≤ 2 m (> 40 in. ≤ 80 in.)	17
3.7.3	Mean Axial Velocity Method	18
3.8	Flow Sensor Alignment	19
4	Electrical Installation	20
4.1	Sensor Terminal Box Connections – WaterMaster FET100 Transmitter	20
4.2	Environmental Protection	21
4.3	Sensor Terminal Box Connections – AquaMaster3 FET200 Transmitter	21
5	Setting Up	22
5.1	Introduction	22
5.2	Centre Line Method	22
5.3	Mean Axial Velocity Method (1/8 Diameter)	23
5.4	Partial Velocity Traverse	23
5.5	Transmitter Setup	23
6	Specification	24

AAquaProbe FEA100 / FEA200

Electromagnetic flowmeter – insertion-type flow sensors

Appendix A	27
A.1 Velocity Profiles Background	27
A.2 Testing the Flow Profile for Symmetry	29
A.2.1 Partial Velocity Traverse	29
A.2.2 Single Entry Point Method	29
A.2.3 Dual Entry Point Method	30
A.3 Full Velocity Profile	30
Appendix B – Measuring the Internal Diameter	31
Notes	32

1 Safety

Information in this manual is intended only to assist our customers in the efficient operation of our equipment. Use of this manual for any other purpose is specifically prohibited and its contents are not to be reproduced in full or part without prior approval of the Technical Publications Department.

1.1 Health & Safety

Health and Safety

To ensure that our products are safe and without risk to health, the following points must be noted:

- The relevant sections of these instructions must be read carefully before proceeding.
- Warning labels on containers and packages must be observed.
- Installation, operation, maintenance and servicing must only be carried out by suitably trained personnel and in accordance with the information given.
- Normal safety precautions must be taken to avoid the possibility of an accident occurring when operating in conditions of high pressure and/or temperature.
- Chemicals must be stored away from heat, protected from temperature extremes and powders kept dry. Normal safe handling procedures must be used.
- When disposing of chemicals ensure that no two chemicals are mixed.

Safety advice concerning the use of the equipment described in this manual or any relevant Material Safety Data Sheets (where applicable) may be obtained from the Company, together with servicing and spares information.






1.2 Electrical Safety – CEI/IEC 61010-1:2001-2











This equipment complies with the requirements of CEI/IEC 61010-1:2001-2 'Safety Requirements for Electrical Equipment for Measurement, Control and Laboratory Use' and complies with US NEC 500, NIST and OSHA.

If the equipment is used in a manner NOT specified by the Company, the protection provided by the equipment may be impaired.


1.3 Symbols – CEI/IEC 61010-1:2001-2

One or more of the following symbols may appear on the equipment labelling:

	Protective earth (ground) terminal.
	Functional earth (ground) terminal.
	Direct current supply only.
	Alternating current supply only.
	Both direct and alternating current supply.

	The equipment is protected through double insulation.
	This symbol, when noted on a product, indicates a potential hazard which could cause serious personal injury and/or death. The user should reference this instruction manual for operation and/or safety information.
	This symbol, when noted on a product enclosure or barrier, indicates that a risk of electrical shock and/or electrocution exists and indicates that only individuals qualified to work with hazardous voltages should open the enclosure or remove the barrier.
	This symbol indicates that the marked item can be hot and should not be touched without care.
	This symbol indicates the presence of devices sensitive to electrostatic discharge and indicates that care must be taken to prevent damage to them.
	This symbol identifies a risk of chemical harm and indicates that only individuals qualified and trained to work with chemicals should handle chemicals or perform maintenance on chemical delivery systems associated with the equipment.
	This symbol indicates the need for protective eye wear.
	This symbol indicates the need for protective hand wear.
	Electrical equipment marked with this symbol may not be disposed of in European public disposal systems. In conformity with European local and national regulations, European electrical equipment users must now return old or end-of-life equipment to the manufacturer for disposal at no charge to the user.
	Products marked with this symbol indicates that the product contains toxic or hazardous substances or elements. The number inside the symbol indicates the environmental protection use period in years.

1.4 Product Recycling Information

	Electrical equipment marked with this symbol may not be disposed of in European public disposal systems after 12 August 2005. In conformity with European local and national regulations (EU Directive 2002/96/EC), European electrical equipment users must now return old or end-of-life equipment to the manufacturer for disposal at no charge to the user.
--	---

Note. For return for recycling, please contact the equipment manufacturer or supplier for instructions on how to return end-of-life equipment for proper disposal.

1.5 Product Disposal

Note. The following only applies to European customers.



ABB is committed to ensuring that the risk of any environmental damage or pollution caused by any of its products is minimized as far as possible. The European Waste Electrical and Electronic Equipment (WEEE) Directive (2002/96/EC) that came into force on August 13 2005 aims to reduce the waste arising from electrical and electronic equipment; and improve the environmental performance of all those involved in the life cycle of electrical and electronic equipment.

In conformity with European local and national regulations (EU Directive 2002/96/EC stated above), electrical equipment marked with the above symbol may not be disposed of in European public disposal systems after 12 August 2005.

1.6 Restriction of Hazardous Substances (RoHS)



The European Union RoHS Directive and subsequent regulations introduced in member states and other countries limits the use of six hazardous substances used in the manufacturing of electrical and electronic equipment. Currently, monitoring and control instruments do not fall within the scope of the RoHS Directive, however ABB has taken the decision to adopt the recommendations in the Directive as the target for all future product design and component purchasing.

1.7 Chemical Reagents

Warning. To familiarize yourself with handling precautions, dangers and emergency procedures, always review the Material Safety Data Sheets prior to handling containers, reservoirs, and delivery systems that contain chemical reagents and standards. Protective eye wear and protective hand wear. is always recommended when contact with chemicals is possible.

1.8 Safety Precautions

Please read the entire manual before unpacking, setting up, or operating this instrument.

Pay particular attention to all warning and caution statements. Failure to do so could result in serious injury to the operator or damage to the equipment.

To ensure the protection provided by this equipment is not impaired, do not use or install this equipment in any manner other than that which is specified in this manual.

1.9 Safety Conventions

Warning. In this manual, a warning is used to indicate a condition which, if not met, could cause serious personal injury and/or death. Do not move beyond a warning until all conditions have been met.

If a warning sign appears on the instrument itself, refer to Precautionary Labels – UL Certification and Electrical Safety – CEI/IEC 61010-1:2001-2 for an explanation.

Caution. A caution is used to indicate a condition which, if not met, could cause minor or moderate personal injury and/or damage to the equipment. Do not move beyond a caution until all conditions have been met.

Note. A note is used to indicate important information or instructions that should be considered before operating the equipment.

1.10 Safety Recommendations

For safe operation, it is imperative that these service instructions be read before use and that the safety recommendations mentioned herein be scrupulously respected. If danger warnings are not heeded to, serious material or bodily injury could occur.

Warning. The installation of the instrument should be performed exclusively by personnel specialized and authorized to work on electrical installations, in accordance with relevant local regulations.

1.11 Service and Repairs

None of the instrument's components can be serviced by the user. Only personnel from ABB or its approved representative(s) is (are) authorized to attempt repairs to the system and only components formally approved by the manufacturer should be used. Any attempt at repairing the instrument in contravention of these principles could cause damage to the instrument and corporal injury to the person carrying out the repair. It renders the warranty null and void and could compromise the correct working of the instrument and the electrical integrity or the CE compliance of the instrument.

If you have any problems with installation, starting, or using the instrument please contact the company that sold it to you. If this is not possible, or if the results of this approach are not satisfactory, please contact the manufacturer's Customer Service

1.12 Potential Safety Hazards

The following potential safety hazards are associated with operating the analyzer:

- Electrical (line voltage)
- Potentially hazardous chemicals

2 System Schematic




Fig. 2.1 System Schematic

Caution.

Care of the Equipment

- The tip of the flow sensor is a precision-built part of the equipment and must be handled with care.
- When the flow sensor is not in use, fully retract the tip of the flow sensor and replace the end-cap.
- When removing / inserting the flow sensor into the pipeline, ensure that the valve is fully open.
- Damage to the flow sensor affects the performance.
- Physical damage to the flow sensor invalidates the warranty.

3 Mechanical Installation

3.1 Location – Environmental Conditions




Fig. 3.1 Environmental Requirements